

These instructions are for your information only.

We **strongly** recommend our professional fitting service.



Remove the rear case by inserting the tool between the front and rear covers then gently pry the metal part out to release the snap catches along the whole edge.



You will now see the battery with its 3 wires leading to the solder pads.



Remove the yellow tape holding the wire and set aside.



Using a fine tipped soldering iron, remove the 3 wires note the order. White. Red, Black. Also note that there is a hole in each solder pad as the wire is removed



Lift out the old battery and install the new one. When soldering the wire back, make sure the end goes through the hole in the solder pad.

When putting the rear cover back, make sure the hold slider is aligned with the switch on the board before squeezing it back together.